



## DESCRIPTION

1. Ensure mains are switched off.
2. Separate the fixing plate (A) from the cover plate (B) by loosening fixing ring's (C) and fixing nut (D).
3. You will need to also unscrew O rings (E) to remove the cover.
4. Install fixing plate (A) to ceiling.
5. Make sure there is enough fixing in the ceiling to suitably support the total weight of the fitting. (Max 18kg).
6. Slide cover plate (B) back onto rods then slide fixing rings (C) onto rod then screw the O rings (E) back onto the rods.
7. Remove all Rods (F) from packaging and determine total drop required. This will be in increments of 250mm.
8. Screw rods together and feed power cable through one side. Do not cut power cable length at this stage.
9. Screw mounting hooks (G) onto the top of the rods.
10. Feed the power cable from the fixture into the hole (H) on the cover plate (B).
11. The fitting will now hang freely allowing you to make final electrical connection.
12. Finish off installation by lifting cover plate and sliding in place.
13. Secure cover plate with fixing nut (D) and by tightening fixing rings (C) in place.
14. Remove glass protective cover (J) and put in appropriate globes.

